

# TL11 LED Driver and LED strip disassembly



TL11-R222 , TL11-R250

Needed tools


Crosshead; Flat; Pliers



Recycle waste



## Driver disassembly



## LED strip disassembly

