

Glamox TL60

Dismantle

Needed tools

T20; H3; H4; Flat; Crosshead; Hammer

