

Glamox TX61

Dismantle



Needed tools

Crosshead; SW4; T20; Flat; SW10; SW29; SW30;
Hammer

