

Glamox TX65

Dismantle



Needed tools

Crosshead; SW5; SW10; T30; SW16; SW20; SW29

